


Lexus (knob) connection diagram

USB Port:connecting USB flash drives/ mobile phones



When the screen flashes,  
Disconnect the connection again(gray)

When the reverse is abnormal,  
Disconnect the connection again(green)

When the screen flashes,  
install the cable again

Default connection

Carplay LVDS

wifi antenna(Keep away from metal)

Add a microphone Bluetooth antenna

( Carplay power cable)

Audio GND(If there is no sound, GND  
and Audio GND are connected)

Transfer the LVDS cable removed from the OEM screen


Connect the LVDS port of the  
OEM screen (blue)

Transfer the power cable removed  
from the OEM CD host

Transfer the power cable removed  
from the OEM CD host

Connect the OEM  
CD host

Connect the OEM  
CD host



Connect the OEM  
CD host

Transfer the power cable removed  
from the OEM CD host

- 1.Short press :Return to the previous level
- 2.Press and hold for 5 seconds:Enter the box system
- 3.Press and hold for 8 seconds:Reset box


Press and hold for 3 seconds:Enter the box system



- 1.Short press :Confirm
- 2.Press and hold for 5 seconds:Activated speech
- 3.Control system:Rotate left/rotate right;  
Move the cursor up/down/left/right

Last song/next song

Control system volume



- 1.Press and hold for 3:Answer calls or hang up

( Dip Switch)

7"/8"

7"/8"



- Note:
- 1.Remove the power cable of the box when replacing the DIP switch
  - 2.Add a microphone:7 ON